



WISYCOM DRIVER FOR UPK, MPR30 AND MRKXXX

To install the USB drivers follow the steps:

- 1) Run WisycomUSBDriver-x64 (for 64bit operating system) or WisycomUSBDriver-x86 (for 32bit operating system)
- 2) Select the products and press next




- 3) Select the destination directory (press Next to use the proposed folder or Browse to change the path)




- 4) **For Windows 7 or older version, go to page 8 (point 8)**
ONLY FOR WINDOWS 8 go to page 2 (point 5), ONLY FOR WINDOWS 8.1 go to page 4 (point 6), ONLY FOR WINDOWS 10 go to page 4 (point 6)

5) ONLY FOR Windows 8


- Access to the main Charm Bar moving the cursor to the bottom right corner and press Setting Charm or press **win + I** → The Settings charm menu will appear.
- Click **Change PC Settings** at the bottom.
- Go to **General**, and scroll to the bottom of the page, click **Restart Now** button under **Advanced Startup** section. Remember to save all your work first before clicking it.




- The computer reboots to a startup menu, in which click **Troubleshoot**.





- Click **Advanced Options** at next screen.



- Choose **Startup Settings** next



g) Click **Restart** button.




h) The computer reboots and prompts another menu to choose. One of the items is to **Disable driver signature enforcement**. Press number **7** or **F7** to continue booting to Windows 8 with digital sign enforcement disabled.


i) **Go to page 8 (point 8) to continue**

6) ONLY FOR Windows 8.1


- a) Press the Win + C keyboard combination to bring up the Charms Bar, then click on the Settings Charm.




- b) We need to head into the Modern Control Panel, so go ahead and click on the Change PC settings link.



- c) When the Control Panel opens, switch over to the "Update & recovery" section.




- d) Then click on the Recovery option on the left hand side.




- e) Once selected, an advanced startup section appear on the right hand side so click on the “Restart now” button.




- f) Once your Computer has rebooted, choose the Troubleshoot option.




g) Then head into Advanced options.




h) Then Startup Settings.



i) Since we are modifying boot time configuration settings, it's necessary to restart your Computer one last time.



- j) Finally, appear a list of startup settings that are possible to change. The one we are looking for is “Disable driver signature enforcement”. To choose the setting, press the F7 key.




- j) Once selected the option to disable driver signature enforcement reboot back into windows.
- k) **Go to page 8 (point 5) to continue**

7) ONLY FOR Windows 10

- a) Press the **Win + C** and click on **PC settings**.
- b) Switch over to the “**Update & recovery**” section.
- c) Then click on the **Recovery option** on the left hand side
- d) Once selected, you will see an advanced startup section appear on the right hand side. You will need to click on the “**Restart now**” button.
- e) Once your Computer has rebooted you will need to choose the **Troubleshoot** option.
- f) Then head into **Advanced options** and then **Startup Settings**
- g) Since we are modifying boot time configuration settings, you will need to restart your computer one last time.
- h) Here you will be given a list of startup settings that you can change. The one we are looking for is “**Disable driver signature enforcement**”. To choose the setting, you will need to press the **F7** key.

- 8) Connect the USB interface of UPKxxx, MPR30 or MRKxxx to the PC

NOTE: WINDOWS 10 and UPKmini driver: the USB port can be recognized as generic USB port like 'USB Serial Port (Com X)' and the driver used is not Wisycom Driver but standard Windows driver: you need to update the driver as indicated below!!!




- 9) Update the drivers going in the **Device Manager** from the **Control Panel**, right click on the hardware's name (Wisycom Device), choose **Update Driver Software** and then follow the instructions
- 10) Browse the computer for driver searching




11) Browse the driver file source.

Usually it's located in C:\Program Files\Wisyscom\Wisyscom USB Drivers (see "destination directory" used in item 3, page 1)



- 12)** You'll received a warning, indicate that the driver is not verified by the publisher, choose "Install this driver software anyway" to continue.



For more information or support, please visit our www.wisycom.com or email us at support@wisycom.com