

Wisyscom frequency table 40 groups of 60 channels (green = open, orange = lock, purple = hidden)

Title WISST104 - USA plan 470-698 MHz

Note: to unlock/unhide area/frequency you cannot do it from receiver, you must use Wisycom Manager Program on a PC connected with the receiver

Date 23/04/2014 @ 16:11:36

	GROUP00	GROUP01	GROUP02	GROUP03	GROUP04	GROUP05	GROUP06	GROUP07	GROUP08	GROUP09
Flag										
Group Name	UNLOCK	ATSC_CAR	INTERGAP	CH 14	CH 15	CH16	CH 17	CH 18	CH 19	CH 20
Group Description	UNLOCK	ATSC Carrier	Intergap	470 476	476 482	482 488	488 494	494 500	500 506	506 512
CH00	470100	470100	470100	470200	476200	482200	488200	494200	500200	506200
CH01	470100	470100	470100	470600	476600	482600	488600	494600	500600	506600
CH02	470100	470100	470100	471200	477200	483200	489200	495200	501200	507200
CH03	470100	470100	470100	472000	478000	484000	490000	496000	502000	508000
CH04	470100	470100	470100	473100	479100	485100	491100	497100	503100	509100
CH05	470100	470100	470100	474000	480000	486000	492000	498000	504000	510000
CH06	470100	470100	470100	474700	480700	486700	492700	498700	504700	510700
CH07	470100	470100	470100	475200	481200	487200	493200	499200	505200	511200
CH08	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH09	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH10	470100	470100	470100	479400	470200	470400	471000	473300	479300	471100
CH11	470100	470100	470100	480700	471500	476200	476400	477000	483000	485300
CH12	470100	470100	470100	482400	487300	477500	482200	482400	488400	489000
CH13	470100	470100	470100	484600	489500	493300	483500	488200	494200	494400
CH14	470100	470375	470100	487200	492500	495500	499300	489500	495500	500200
CH15	470100	476375	476000	490500	494800	498600	501500	505300	511300	501500
CH16	470100	482375	482000	496900	499700	501000	504600	507500	513500	517300
CH17	470100	488375	488000	501800	503400	507200	507000	510600	516600	519500
CH18	470100	494375	494000	505400	506500	511600	513200	513000	519000	522600
CH19	470100	500375	500000	512000	511300	517200	517600	519200	525200	525000
CH20	470100	506375	506000	515700	514600	524100	523500	523600	529600	531200
CH21	470100	512375	512000	518100	520000	532500	535500	529500	535500	535600
CH22	470100	518375	518000	531200	532000	541500	539200	541500	547500	541500
CH23	470100	524375	524000	538200	536200	543800	543400	546400	552400	557200
CH24	470100	530375	530000	544000	544200	547400	550800	549400	555400	561400
CH25	470100	536375	536000	549600	551600	560500	554700	556300	562300	569300
CH26	470100	542375	542000	558700	564600	567200	568100	567900	573900	578000
CH27	470100	548375	548000	567300	567200	585900	575300	576000	582000	580600
CH28	470100	554375	554000	580600	581000	589200	587700	581600	587600	590000
CH29	470100	560375	560000	582100	587200	598300	604400	599000	605000	605100
CH30	470100	566375	566000	597700	601500	600000	622100	602300	617700	618800
CH31	470100	572375	572000	606700	605100	619600	631100	619800	625200	636900
CH32	470100	578375	578000	627400	620200	627500	470100	631100	637300	470100
CH33	470100	584375	584000	631700	629800	470100	470100	635300	470100	470100
CH34	470100	590375	590000	637000	637500	470100	470100	470100	470100	470100
CH35	470100	596375	596000	470100	470100	470100	470100	470100	470100	470100
CH36	470100	602375	602000	470100	470100	470100	470100	470100	470100	470100
CH37	470100	608375	608000	470100	470100	470100	470100	470100	470100	470100
CH38	470100	614375	614000	470100	470100	470100	470100	470100	470100	470100
CH39	470100	620375	620000	470100	470100	470100	470100	470100	470100	470100
CH40	470100	626375	626000	470100	470100	470100	470100	470100	470100	470100
CH41	470100	632375	632000	470100	470100	470100	470100	470100	470100	470100
CH42	470100	638375	638000	470100	470100	470100	470100	470100	470100	470100
CH43	470100	644375	644000	470100	470100	470100	470100	470100	470100	470100
CH44	470100	650375	650000	470100	470100	470100	470100	470100	470100	470100
CH45	470100	656375	656000	470100	470100	470100	470100	470100	470100	470100
CH46	470100	662375	662000	470100	470100	470100	470100	470100	470100	470100
CH47	470100	668375	668000	470100	470100	470100	470100	470100	470100	470100
CH48	470100	674375	674000	470100	470100	470100	470100	470100	470100	470100
CH49	470100	680375	680000	470100	470100	470100	470100	470100	470100	470100
CH50	470100	686375	686000	470100	470100	470100	470100	470100	470100	470100
CH51	470100	692375	692000	470100	470100	470100	470100	470100	470100	470100
CH52	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH53	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH54	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH55	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH56	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH57	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH58	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH59	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100

Wisyscom frequency table 40 groups of 60 channels (green = open, orange = lock, purple = hidden)

Title WISST104 - USA plan 470-698 MHz

Note: to unlock/unhide area/frequency you cannot do it from receiver, you must use Wisycom Manager Program on a PC connected with the receiver

Date 23/04/2014 @ 16:11:36

	GROUP10	GROUP11	GROUP12	GROUP13	GROUP14	GROUP15	GROUP16	GROUP17	GROUP18	GROUP19
Flag										
Group Name	CH 21	CH 22	CH 23	CH 24	CH 25	CH 26	CH 27	CH 28	CH 29	CH 30
Group Description	512 518	518 524	524 530	530 536	536 542	542 548	548 554	554 560	560 566	566 572
CH00	512200	518200	524200	530200	536200	542200	548200	554200	560200	566200
CH01	512600	518600	524600	530600	536600	542600	548600	554600	560600	566600
CH02	513200	519200	525200	531200	537200	543200	549200	555200	561200	567200
CH03	514000	520000	526000	532000	538000	544000	550000	556000	562000	568000
CH04	515100	521100	527100	533100	539100	545100	551100	557100	563100	569100
CH05	516000	522000	528000	534000	540000	546000	552000	558000	564000	570000
CH06	516700	522700	528700	534700	540700	546700	552700	558700	564700	570700
CH07	517200	523200	529200	535200	541200	547200	553200	559200	565200	571200
CH08	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH09	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH10	521400	510500	512400	513000	515300	521300	513100	511000	511900	521700
CH11	522700	512200	518200	518400	519000	525000	527300	519100	515200	531100
CH12	524400	513500	519500	524200	524400	530400	531000	533300	525100	545300
CH13	526600	529300	535300	525500	530200	536200	536400	537000	539300	549000
CH14	529200	534500	537500	541300	531500	537500	542200	542400	543000	554400
CH15	532500	536800	540600	543500	547300	553300	543500	548200	548400	560200
CH16	538900	540700	543000	546600	549500	555500	559300	549500	554200	561500
CH17	543800	543100	549200	549000	552600	558600	561500	565300	555500	577300
CH18	547400	548700	553600	555200	555000	561000	564600	567500	571300	579500
CH19	554000	553000	559200	559600	561200	567200	567000	570600	573500	582600
CH20	557700	556100	566100	565500	565600	571600	573200	573000	576600	585000
CH21	560100	562000	574500	577500	571500	577500	577600	579200	579000	591200
CH22	573200	570400	583500	581200	583500	589500	583500	583600	585200	595600
CH23	580200	580400	585800	585400	588400	594400	599200	589500	589600	601500
CH24	586000	587600	589400	592800	591400	597400	603400	607000	595500	617200
CH25	591600	599600	602500	596700	598300	604300	614700	616900	615400	621400
CH26	600700	602200	616500	615400	618000	615900	622600	627700	621000	629300
CH27	615700	614600	618200	617100	621300	624000	632200	630000	634100	638000
CH28	622600	623400	626100	626200	622800	629600	637800	470100	470100	470100
CH29	629900	633600	636900	470100	632200	470100	470100	470100	470100	470100
CH30	470100	639000	470100	470100	636500	470100	470100	470100	470100	470100
CH31	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH32	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH33	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH34	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH35	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH36	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH37	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH38	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH39	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH40	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH41	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH42	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH43	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH44	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH45	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH46	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH47	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH48	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH49	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH50	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH51	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH52	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH53	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH54	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH55	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH56	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH57	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH58	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH59	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100

Wisyscom frequency table 40 groups of 60 channels (green = open, orange = lock, purple = hidden)

Title WISST104 - USA plan 470-698 MHz

Note: to unlock/unhide area/frequency you cannot do it from receiver, you must use Wisycom Manager Program on a PC connected with the receiver

Date 23/04/2014 @ 16:11:36

[illegible]

Wisyscom frequency table 40 groups of 60 channels (green = open, orange = lock, purple = hidden)

Title WISST104 - USA plan 470-698 MHz

Note: to unlock/unhide area/frequency you cannot do it from receiver, you must use Wisycom Manager Program on a PC connected with the receiver

Date 23/04/2014 @ 16:11:36

	GROUP30	GROUP31	GROUP32	GROUP33	GROUP34	GROUP35	GROUP36	GROUP37	GROUP38	GROUP39
Flag										
Group Name	CH 42	CH 43	CH 44	CH 45	CH 46	CH 47	CH 48	CH 49	CH 50	CH 51
Group Description	638 644	644 650	650 656	656 662	662 668	668 674	674 680	680 686	686 692	692 698
CH00	638200	644200	650200	656800	662800	668800	674800	680800	686800	692800
CH01	638600	644600	650600	657300	663300	669300	675300	681300	687300	693300
CH02	639200	645200	651200	658000	664000	670000	676000	682000	688000	694000
CH03	640000	646000	652000	658900	664900	670900	676900	682900	688900	694900
CH04	641100	647100	653100	660000	666000	672000	678000	684000	690000	696000
CH05	642000	648000	654000	660800	666800	672800	678800	684800	690800	696800
CH06	642700	648700	654700	661400	667400	673400	679400	685400	691400	697400
CH07	643200	649200	655200	661800	667800	673800	679800	685800	691800	697800
CH08	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH09	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH10	515300	524400	517900	515400	519500	529900	514800	518300	524300	512600
CH11	517900	538600	524800	529900	526400	537400	519000	527300	529700	531500
CH12	527400	543900	530900	538900	543300	545400	534200	549000	536400	542500
CH13	548500	560500	558200	554100	548700	559900	547900	554600	554700	565200
CH14	552400	562800	561300	564200	564900	574100	566500	558900	565300	572000
CH15	554800	578500	565500	578500	572800	578400	574600	582700	568900	579000
CH16	570100	587200	580900	582700	584100	591800	587300	586000	578800	584800
CH17	579400	588900	588300	590600	599100	602000	589900	596900	599600	592100
CH18	580900	592000	591300	596000	600800	605900	600700	603700	602000	604800
CH19	584600	602200	603300	602200	603900	618600	605000	620600	614800	607100
CH20	592100	606400	607000	604800	617200	621600	615200	623600	616300	622500
CH21	596300	614300	615000	615200	621100	626500	624600	627800	632500	626800
CH22	602200	632400	620300	632300	629900	638500	627600	633000	636800	644600
CH23	604500	634600	638400	636700	632300	644400	632500	645100	647100	647000
CH24	614800	638200	640600	638200	638500	648800	644500	650500	653400	650700
CH25	620300	639500	644200	640600	645300	655000	650400	656400	656700	656000
CH26	622000	655500	645500	644900	650800	657400	654800	660800	661500	662600
CH27	626400	661100	661500	650500	653400	660500	661000	667000	664600	666200
CH28	628600	665400	667100	666500	656700	662700	663400	669400	668300	671100
CH29	632200	667800	671400	667800	672500	678500	666500	672500	673200	677500
CH30	633500	669300	673800	671400	673800	679800	668700	674700	675500	680800
CH31	470100	673700	675300	673600	679600	685600	684500	690500	678500	683400
CH32	470100	688900	679700	691700	683300	691000	685800	691800	680700	685600
CH33	470100	470100	696800	697000	688600	694700	691600	697600	696500	687300
CH34	470100	470100	470100	470100	470100	470100	697000	470100	697800	688600
CH35	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH36	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH37	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH38	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH39	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH40	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH41	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH42	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH43	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH44	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH45	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH46	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH47	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH48	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH49	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH50	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH51	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH52	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH53	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH54	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH55	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH56	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH57	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH58	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH59	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100