



Note: to unlock/unhide area/frequency you cannot do it from receiver, you must use Wisycom Manager Program on a PC connected with the receiver

	GROUP00	GROUP01	GROUP02	GROUP03	GROUP04	GROUP05	GROUP06	GROUP07	GROUP08	GROUP09
Flag										
Group Name	UNLOCK	ATSC_CAR	INTERGAP	TV CH 14	TV CH 15	TV CH 16	TV CH 17	TV CH 18	TV CH 19	TV CH 20
Group Description	UNLOCK	ATSC Carrier	Intergap	470 476	476 482	482 488	488 494	494 500	500 506	506 512
CH00	470100	470100	470100	470200	476200	482200	488200	494200	500200	506200
CH01	470100	470100	470100	470600	476600	482600	488600	494600	500600	506600
CH02	470100	470100	470100	471200	477200	483200	489200	495200	501200	507200
CH03	470100	470100	470100	472000	478000	484000	490000	496000	502000	508000
CH04	470100	470100	470100	473100	479100	485100	491100	497100	503100	509100
CH05	470100	470100	470100	474000	480000	486000	492000	498000	504000	510000
CH06	470100	470100	470100	474700	480700	486700	492700	498700	504700	510700
CH07	470100	470100	470100	475200	481200	487200	493200	499200	505200	511200
CH08	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH09	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH10	470100	470100	470100	479400	470200	470400	471000	473300	479300	471100
CH11	470100	470100	470100	480700	471500	476200	476400	477000	483000	485300
CH12	470100	470100	470100	482400	487300	477500	482200	482400	488400	489000
CH13	470100	470100	470100	484600	489500	493300	483500	488200	494200	494400
CH14	470100	470375	470100	487200	492500	495500	499300	489500	495500	500200
CH15	470100	476375	476000	490500	494800	498600	501500	505300	511300	501500
CH16	470100	482375	482000	496900	499700	501000	504600	507500	513500	517300
CH17	470100	488375	488000	501800	503400	507200	507000	510600	516600	519500
CH18	470100	494375	494000	505400	506500	511600	513200	513000	519000	522600
CH19	470100	500375	500000	512000	511300	517200	517600	519200	525200	525000
CH20	470100	506375	506000	515700	514600	524100	523500	523600	529600	531200
CH21	470100	512375	512000	518100	520000	532500	535500	529500	535500	535600
CH22	470100	518375	518000	531200	532000	541500	539200	541500	547500	541500
CH23	470100	524375	524000	538200	536200	543800	543400	546400	552400	557200
CH24	470100	530375	530000	544000	544200	547400	550800	549400	555400	561400
CH25	470100	536375	536000	549600	551600	560500	554700	556300	562300	569300
CH26	470100	542375	542000	558700	564600	567200	568100	567900	573900	578000
CH27	470100	548375	548000	567300	567200	585900	575300	576000	582000	580600
CH28	470100	554375	554000	580600	581000	589200	587700	581600	587600	590000
CH29	470100	560375	560000	582100	587200	598300	604400	599000	605000	605100
CH30	470100	566375	566000	597700	601500	600000</				

Wisyscom frequency table 40 groups of 60 channels (green = open, orange = lock, purple = hidden)

Title WISST113 - USA plan B7(470-663) & B8(940-960)

Note: to unlock/unhide area/frequency you cannot do it from receiver, you must use Wisycom Manager Program on a PC connected with the receiver

Date 07/01/2019 @ 09:21:46

	GROUP10	GROUP11	GROUP12	GROUP13	GROUP14	GROUP15	GROUP16	GROUP17	GROUP18	GROUP19
Flag										
Group Name	TV CH 21	TV CH 22	TV CH 23	TV CH 24	TV CH 25	TV CH 26	TV CH 27	TV CH 28	TV CH 29	TV CH 30
Group Description	512 518	518 524	524 530	530 536	536 542	542 548	548 554	554 560	560 566	566 572
CH00	512200	518200	524200	530200	536200	542200	548200	554200	560200	566200
CH01	512600	518600	524600	530600	536600	542600	548600	554600	560600	566600
CH02	513200	519200	525200	531200	537200	543200	549200	555200	561200	567200
CH03	514000	520000	526000	532000	538000	544000	550000	556000	562000	568000
CH04	515100	521100	527100	533100	539100	545100	551100	557100	563100	569100
CH05	516000	522000	528000	534000	540000	546000	552000	558000	564000	570000
CH06	516700	522700	528700	534700	540700	546700	552700	558700	564700	570700
CH07	517200	523200	529200	535200	541200	547200	553200	559200	565200	571200
CH08	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH09	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH10	521400	510500	512400	513000	515300	521300	513100	511000	511900	521700
CH11	522700	512200	518200	518400	519000	525000	527300	519100	515200	531100
CH12	524400	513500	519500	524200	524400	530400	531000	533300	525100	545300
CH13	526600	529300	535300	525500	530200	536200	536400	537000	539300	549000
CH14	529200	534500	537500	541300	531500	537500	542200	542400	543000	554400
CH15	532500	536800	540600	543500	547300	553300	543500	548200	548400	560200
CH16	538900	540700	543000	546600	549500	555500	559300	549500	554200	561500
CH17	543800	543100	549200	549000	552600	558600	561500	565300	555500	577300
CH18	547400	548700	553600	555200	555000	561000	564600	567500	571300	579500
CH19	554000	553000	559200	559600	561200	567200	567000	570600	573500	582600
CH20	557700	556100	566100	565500	565600	571600	573200	573000	576600	585000
CH21	560100	562000	574500	577500	571500	577500	577600	579200	579000	591200
CH22	573200	570400	583500	581200	583500	589500	583500	583600	585200	595600
CH23	580200	580400	585800	585400	588400	594400	599200	589500	589600	601500
CH24	586000	587600	589400	592800	591400	597400	603400	607000	595500	663000
CH25	591600	599600	602500	596700	598300	604300	614700	663000	615400	663000
CH26	600700	602200	663000	615400	663000	615900	663000	663000	663000	663000
CH27	615700	614600	663000	663000	663000	663000	663000	663000	663000	663000
CH28	663000	663000	663000	663000	663000	663000	663000	470100	470100	470100
CH29	663000	663000	663000	470100	663000	470100	470100	470100	470100	470100
CH30	470100	663000	470100	470100	663000	470100	470100	470100	470100	470100
CH31	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH32	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH33	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH34	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH35	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH36	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH37	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH38	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH39	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH40	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH41	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH42	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH43	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH44	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH45	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH46	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH47	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH48	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH49	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH50	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH51	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH52	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH53	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH54	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH55	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH56	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH57	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH58	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH59	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100

Note: to unlock/unhide area/frequency you cannot do it from receiver, you must use Wisycom Manager Program on a PC connected with the receiver

must use Wisycom Manager Program on a PC connected with the receiver

	GROUP20	GROUP21	GROUP22	GROUP23	GROUP24	GROUP25	GROUP26	GROUP27	GROUP28	GROUP29
Flag										
Group Name	TV CH 31	TV CH 32	TV CH 33	TV CH 34	TV CH 35	TV CH 36	TV CH 38	TV CH 39	TV CH 40	TV CH 41
Group Description	572 578	578 584	584 590	590 596	596 602	602 608	614 620	620 626	626 632	632 638
CH00	572200	578200	584200	590200	596200	602200	614200	663000	663000	663000
CH01	572600	578600	584600	590600	596600	602600	614600	663000	663000	663000
CH02	573200	579200	585200	591200	597200	603200	615200	663000	663000	663000
CH03	574000	580000	586000	592000	598000	604000	663000	663000	663000	663000
CH04	575100	581100	587100	593100	599100	605100	663000	663000	663000	663000
CH05	576000	582000	588000	594000	600000	606000	663000	663000	663000	663000
CH06	576700	582700	588700	594700	600700	606700	663000	663000	663000	663000
CH07	577200	583200	589200	595200	601200	607200	663000	663000	663000	663000
CH08	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH09	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH10	512600	514200	514000	518800	510800	516000	513600	513800	512300	515100
CH11	514300	525800	524300	521200	519900	520800	524400	523400	529900	529900
CH12	527700	530700	530600	536700	535900	526600	531500	535100	542300	544200
CH13	537100	533700	552100	551100	548600	533700	542200	537400	550000	555100
CH14	551300	537900	560800	558800	551000	550900	548800	541000	560200	557500
CH15	555000	543100	563400	566800	555300	558100	560200	548200	567700	566800
CH16	560400	557300	567000	569400	564100	566800	566300	561900	571000	572000
CH17	566200	561000	572400	573000	567400	569000	568700	566800	579600	573500
CH18	567500	566400	578200	578400	578900	572700	578600	582300	585000	580700
CH19	583300	572200	579500	584200	584400	576900	585800	584900	593300	584600
CH20	585500	573500	595300	585500	586600	590600	592600	590200	600200	592300
CH21	588600	589300	597500	601300	590200	593200	600400	591700	602800	596600
CH22	591000	591500	600600	603500	591500	596200	602600	596500	604500	602200
CH23	597200	594600	603000	606600	607300	597500	606200	602300	607600	605200
CH24	601600	597000	663000	663000	615200	615300	607700	605600	614400	614300
CH25	607500	603200	663000	663000	663000	663000	663000	614200	663000	663000
CH26	663000	607600	663000	663000	663000	663000	663000	615500	663000	663000
CH27	663000	614500	663000	663000	663000	663000	663000	663000	663000	663000
CH28	470100	470100	470100	470100	663000	663000	663000	663000	663000	663000
CH29	470100	470100	470100	470100	470100	663000	470100	663000	470100	663000
CH30	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH31	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH32	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH33	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH34	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH35	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH36	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH37	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH38	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH39	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH40	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH41	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH42	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH43	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH44	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH45	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH46	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH47	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH48	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH49	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH50	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH51	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH52	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH53	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH54	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH55	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH56	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH57	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH58	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100
CH59	470100	470100	470100	470100	470100	470100	470100	470100	470100	470100

Wisyscom frequency table 40 groups of 60 channels (green = open, orange = lock, purple = hidden)

Title WISST113 - USA plan B7(470-663) & B8(940-960)

Note: to unlock/unhide area/frequency you cannot do it from receiver, you must use Wisyscom Manager Program on a PC connected with the receiver

Date 07/01/2019 @ 09.21.46

	GROUP30	GROUP31	GROUP32	GROUP33	GROUP34	GROUP35	GROUP36	GROUP37	GROUP38	GROUP39
Flag										
Group Name	TV CH 42	TV CH 43	TV CH 44	TV CH 45	UNLOCK	250kHzLI	250kHzLI	200kHzLI	200kHzLI	NOT LI
Group Description	638 644	644 650	650 656	656 662	UNLOCK	20L mW equispaced 250kHz	20L mW equispaced 250kHz	20L mW equispaced 200kHz	20L mW equispaced 200kHz	power 20/50/100mW
CH00	663000	663000	663000	656800	470100	941500	941500	941500	941500	941500
CH01	663000	663000	663000	657300	470100	941500	952850	941500	952850	941575
CH02	663000	663000	663000	658000	470100	941750	953100	941700	953050	942000
CH03	663000	663000	663000	658900	470100	942000	953350	941900	953250	942250
CH04	663000	663000	653100	660000	470100	942250	953600	942100	953450	942600
CH05	663000	663000	654000	660800	470100	942500	953850	942300	953650	943100
CH06	663000	663000	654700	661400	470100	942750	954100	942500	953850	943850
CH07	663000	663000	655200	661800	470100	943000	954350	942700	954050	945200
CH08	470100	470100	470100	470100	470100	943250	954600	942900	954250	948000
CH09	470100	470100	470100	470100	470100	943500	954850	943100	954450	948925
CH10	515300	524400	517900	515400	470100	943750	955100	943300	954650	950350
CH11	517900	538600	524800	529900	470100	944000	955350	943500	954850	953225
CH12	527400	543900	530900	538900	470100	944250	955600	943700	955050	955000
CH13	548500	560500	558200	554100	470100	944500	955850	943900	955250	957175
CH14	552400	562800	561300	564200	470100	944750	956100	944100	955450	958850
CH15	554800	578500	565500	578500	470100	945000	956600	944300	955650	941500
CH16	570100	587200	580900	582700	470100	945250	956850	944500	955850	941500
CH17	579400	588900	588300	590600	470100	945500	957100	944700	956050	941500
CH18	580900	592000	591300	596000	470100	945750	957350	944900	956250	941500
CH19	584600	602200	603300	602200	470100	946000	957600	945100	956450	941500
CH20	592100	606400	607000	604800	470100	946250	957850	945300	956650	941500
CH21	596300	614300	615000	615200	470100	946500	958100	945500	956850	941500
CH22	602200	663000	663000	663000	470100	946750	958350	945700	957050	941500
CH23	604500	663000	663000	663000	470100	947000	958600	945900	957250	941500
CH24	614800	663000	663000	663000	470100	947250	958850	946100	957450	941500
CH25	663000	663000	663000	663000	470100	947500	959100	946300	957650	941500
CH26	663000	655500	663000	663000	470100	947750	959350	946500	957850	941500
CH27	663000	661100	661500	663000	470100	948000	959600	946700	958050	941500
CH28	663000	663000	663000	663000	470100	948250	959850	946900	958250	941500
CH29	663000	663000	663000	663000	470100	948500	941500	947100	958450	941500
CH30	663000	663000	663000	663000	470100	948750	941500	947300	958650	941500
CH31	470100	663000	663000	663000	470100	949000	941500	947500	958850	941500
CH32	470100	663000	663000	663000	470100	949250	941500	947700	959050	941500
CH33	470100	470100	663000	663000	470100	949500	941500	947900	959250	941500
CH34	470100	470100	470100	470100	470100	949750	941500	948100	959450	941500
CH35	470100	470100	470100	470100	470100	950000	941500	948300	959650	941500
CH36	470100	470100	470100	470100	470100	950250	941500	948500	959850	941500
CH37	470100	470100	470100	470100	470100	950500	941500	948700	941500	941500
CH38	470100	470100	470100	470100	470100	950750	941500	948900	941500	941500
CH39	470100	470100	470100	470100	470100	951000	941500	949100	941500	941500
CH40	470100	470100	470100	470100	470100	951250	941500	949300	941500	941500
CH41	470100	470100	470100	470100	470100	951500	941500	949500	941500	941500
CH42	470100	470100	470100	470100	470100	951750	941500	949700	941500	941500
CH43	470100	470100	470100	470100	470100	952000	941500	949900	941500	941500
CH44	470100	470100	470100	470100	470100	941500	941500	950100	941500	941500
CH45	470100	470100	470100	470100	470100	941500	941500	950300	941500	941500
CH46	470100	470100	470100	470100	470100	941500	941500	950500	941500	941500
CH47	470100	470100	470100	470100	470100	941500	941500	950700	941500	941500
CH48	470100	470100	470100	470100	470100	941500	941500	950900	941500	941500
CH49	470100	470100	470100	470100	470100	941500	941500	951100	941500	941500
CH50	470100	470100	470100	470100	470100	941500	941500	951300	941500	941500
CH51	470100	470100	470100	470100	470100	941500	941500	951500	941500	941500
CH52	470100	470100	470100	470100	470100	941500	941500	951700	941500	941500
CH53	470100	470100	470100	470100	470100	941500	941500	951900	941500	941500
CH54	470100	470100	470100	470100	470100	941500	941500	941500	941500	941500
CH55	470100	470100	470100	470100	470100	941500	941500	941500	941500	941500
CH56	470100	470100	470100	470100	470100	941500	941500	941500	941500	941500
CH57	470100	470100	470100	470100	470100	941500	941500	941500	941500	941500
CH58	470100	470100	470100	470100	470100	941500	941500	941500	941500	941500
CH59	470100	470100	470100	470100	470100	941500	941500	941500	941500	941500